

FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: McDonnell Douglas DC-9-10/-20/-30/-40/-50/-80 Series and MD-88/-90 Series

Configuration: 1

DC-9/MD-80 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-22566-801 **AFMS:** N/A

Master Kit List: 2-22566-802 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	MD90-ELT-1	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Boeing B747-100/-200B/-200F/-200C/-300/-SP/-400 Series

Configuration: 2

B747 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-22566-803 **AFMS:** N/A

Master Kit List: 2-22566-804 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B747-ELT-2	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Boeing B737-300/-400/-500 Series

Configuration: 3

B737CL Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-23501-801 **AFMS:** N/A

Master Kit List: 2-23501-802 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B737-ELT-1	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Boeing B777-200 Series

Configuration: 4

B777 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-22566-816 **AFMS:** N/A

Master Kit List: 2-22566-815 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B777-ELT-1	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: McDonnell Douglas DC-10-30/MD-11 Series

Configuration: 5

DC-10/MD-11 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-22566-820 **AFMS:** N/A

Master Kit List: 2-22566-821 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	MD11-ELT-1	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Boeing B727-100/-200 Series

Configuration: 6

B727 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-34239-801 **AFMS:** N/A

Master Kit List: 2-31038-801 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B727-ELT-900	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Boeing B737-100/-200 Series

Configuration: 7

B737 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-33049-820 **AFMS:** N/A

Master Kit List: 2-23501-802 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B737-ELT-1	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Boeing B757-200 Series

Configuration: 8

B757 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-33049-830 **AFMS:** N/A

Master Kit List: 2-33049-831 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B757-ELT-903	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Airbus A300B2-203/B4-103/B4-203 and A310-200/-300 Series

Configuration: 9

A300/310 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-32457-800 **AFMS:** N/A

Master Kit List: 2-31535-801 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	A300-ELT-1	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Boeing B767-200/-300 Series

Configuration: 10

B767 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-36425-801 **AFMS:** N/A

Master Kit List: 2-33258-811 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B767-ELT-901	Kit, Artex 406 ELT Installation	B/E Aerospace

FAA STC ST02929AT Rev. 1/10/2014 Page 10 of 14

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: British Aerospace (Operations Limited) Jetstream 3101/3201 Series

Configuration: 11

J31/32 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-37239-801 **AFMS:** N/A

Master Kit List: 2-37239-802 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-338*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	355-6196*	Remote Switch	ARTEX
1	J3132-ELT-900	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5014-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Boeing B737-600/-700/-800/-900 Series

Configuration: 12

B737NG Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-39885-810 **AFMS:** N/A

Master Kit List: 2-23501-802 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B737-ELT-1	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Boeing B707-300/-400 Series

Configuration: 13

B707 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-55135-801 **AFMS:** N/A

Master Kit List: 2-55135-803 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B707-ELT-900	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010



FAA STC: ST02929AT Master Drawing List: 2-22566-001

Approved Model List: 2-22566-002

Aircraft: Airbus A300-600 Series

Configuration: 14

A300-600 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

Mod. Order: 2-106336-801 **AFMS:** N/A

Master Kit List: 2-31535-801 ICA: 2-22566-905

Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

QTY	Part Number	Description	Source/MFGR
1	453-5002-()*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	A300-ELT-1	Kit, Artex 406 ELT Installation	B/E Aerospace

^{*} Included in Artex Kit 455-5015-XXX

^{**} Included in Artex Kit 455-4010