



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** McDonnell Douglas DC-9-10/-20/-30/-40/-50/-80 Series and MD-88/-90 Series

**Configuration:** 1

DC-9/MD-80 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-22566-801

**AFMS:** N/A

**Master Kit List:** 2-22566-802

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	MD90-ELT-1	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Boeing B747-100/-200B/-200F/-200C/-300/-SP/-400 Series

**Configuration:** 2

B747 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-22566-803

**AFMS:** N/A

**Master Kit List:** 2-22566-804

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B747-ELT-2	Kit, Artex 406 ELT Installation	Woven Electronics, LLC

## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Boeing B737-300/-400/-500 Series

**Configuration:** 3

B737CL Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-23501-801

**AFMS:** N/A

**Master Kit List:** 2-23501-802

**ICA:** 2-22566-905

**Summary:**

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

**Notes:**

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

**Material List**

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B737-ELT-1	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Boeing B777-200 Series

**Configuration:** 4

B777 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-22566-816

**AFMS:** N/A

**Master Kit List:** 2-22566-815

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B777-ELT-1	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** McDonnell Douglas DC-10-30/MD-11 Series

**Configuration:** 5

DC-10/MD-11 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-22566-820

**AFMS:** N/A

**Master Kit List:** 2-22566-821

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	MD11-ELT-1	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Boeing B727-100/-200 Series

**Configuration:** 6

B727 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-34239-801

**AFMS:** N/A

**Master Kit List:** 2-31038-801

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B727-ELT-900	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Boeing B737-100/-200 Series

**Configuration:** 7

B737 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-33049-820

**AFMS:** N/A

**Master Kit List:** 2-23501-802

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B737-ELT-1	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Boeing B757-200 Series

**Configuration:** 8

B757 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-33049-830

**AFMS:** N/A

**Master Kit List:** 2-33049-831

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B757-ELT-903	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Airbus A300B2-203/B4-103/B4-203 and A310-200/-300 Series

**Configuration:** 9

A300/310 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-32457-800

**AFMS:** N/A

**Master Kit List:** 2-31535-801

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	A300-ELT-1	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Boeing B767-200/-300 Series

**Configuration:** 10

B767 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-36425-801

**AFMS:** N/A

**Master Kit List:** 2-33258-811

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B767-ELT-901	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** British Aerospace (Operations Limited) Jetstream 3101/3201 Series

**Configuration:** 11

J31/32 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-37239-801

**AFMS:** N/A

**Master Kit List:** 2-37239-802

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5014-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-338*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	355-6196*	Remote Switch	ARTEX
1	J3132-ELT-900	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Boeing B737-600/-700/-800/-900 Series

**Configuration:** 12

B737NG Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-39885-810

**AFMS:** N/A

**Master Kit List:** 2-23501-802

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B737-ELT-1	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Boeing B707-300/-400 Series

**Configuration:** 13

B707 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-55135-801

**AFMS:** N/A

**Master Kit List:** 2-55135-803

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	B707-ELT-900	Kit, Artex 406 ELT Installation	Woven Electronics, LLC



## STC Information Sheet

**FAA STC:** ST02929AT

**Master Drawing List:** 2-22566-001

**Approved Model List:** 2-22566-002

**Aircraft:** Airbus A300-600 Series

**Configuration:** 14

A300-600 Series – Artex C406-1 Emergency Locator Transmitter (ELT) Installation

**Mod. Order:** 2-106336-801

**AFMS:** N/A

**Master Kit List:** 2-31535-801

**ICA:** 2-22566-905

### Summary:

The Artex C406-1 Emergency Locator Transmitter (ELT) system consists of the ELT transmitter installed in the aft overhead cabin adjacent to the ELT antenna on the upper aft fuselage. Connected to the ELT transmitter is a programming dongle. Finally, a Remote Switch is installed in the cockpit to control the ELT system.

### Notes:

This is an Approved Model List (AML) STC that includes various aircraft types.

\* Included in Artex Kit 455-5015-XXX

\*\* Included in Artex Kit 455-4010

### Material List

QTY	Part Number	Description	Source/MFGR
1	453-5002-( )*	ELT Transmitter	ARTEX
1	110-340*	ELT Antenna	ARTEX
1	455-4010-01**	Programming Dongle	ARTEX
1	345-6196-04*	Remote Switch	ARTEX
1	A300-ELT-1	Kit, Artex 406 ELT Installation	Woven Electronics, LLC